

# SPILL RESPONSE KIT

## HAZ - MAT

NO. HAZ-095

360 Litres / 95 Gal. DRUM  
C/W SCREW ON COVER

UNIVERSAL

**NOTE\*: PRIOR TO RESPONDING TO A HAZARDOUS LIQUID SPILL, INSURE ALL SAFETY PRECAUTIONS ARE TAKEN. ENSURE; PROTECTIVE CLOTHING, GLOVES AND GOGGLES ARE DONNED. ENSURE ROOM OR BUILDING IS WELL VENTILATED.**

**SORBENTS WILL CLEAN UP MOST LIQUIDS INCLUDING; AGGRESSIVE ACIDS, OILS/FUELS, AND OTHER WATER SOLUBLE CHEMICALS. USED ON LAND BASED SPILLS ONLY. ABSORBS AND CONTROLS UP TO 340 Liters / 90 Gals OF LIQ**

#48000 2 - 25 LB. BAG MAGIC SORB  
#B5-H 4 - SORBENT BOOM (5"X10")  
#P12P 2 - BALES SORBENT PADS 100/BALE (17" X 19")  
1 - PR. COVERALLS  
1 - PR. PVC GLOVES  
1 - PR. GOGGLES  
4 - LARGE HEAVY DUTY DISPOSAL BAGS

**INSTRUCTIONS:**

- 1.A. PLACE A DAM OF MAGIC SORB AROUND SPILL.
- B. COVER SPILL COMPLETELY WITH MAGIC SORB.
2. IMMEDIATELY SWEEP MAGIC SORB PART WAY THROUGH SPILL THEN TOPPLE BACK AND FORTH. CONTINUE FROM ALL DIRECTIONS UNTIL SPILL IS COMPLETELY PICKED UP. SWEEP ASIDE.
3. LIGHTLY RE-APPLY MAGIC SORB AND SWEEP/SWIRL OVER SPILL AREA TO REMOVE ANY REMAINING SPILL RESIDUE.
4. BOOMS MAY BE USED TO ASSIST IN DAMMING, DEFLECTING SPILLED LIQUID AWAY FROM DRAINS, DITCHES, OR TO CONTAIN LIQUID AROUND DRUMS OR TANKS.
5. SORBENT PADS MAY BE USED IN MOPPING UP OPERATION, INSIDE OF DYKED AREAS, OR PLACED UNDER LEAKING DRUMS, TANKS, OR MACHINERY.
6. SWEEP UP MAGIC SORB, REMOVE ALL SORBENT PRODUCTS AND MATERIALS, AND DISPOSE ACCORDING TO LOCAL, STATE, PROVINCIAL AND FEDERAL REGULATIONS FOR SORBED LIQUIDS.

**\* NOTE:** #48000-MAGIC SORB SHOULD NOT BE USED TO ABSORB HYDROFLUORIC ACID OR RELATED FLUORIDE CONTAINING COMPOUNDS. REACTION OF FLUORINE WITH THE SILICATE MATERIALS IN THIS PRODUCT WILL PRODUCE THE HIGHLY TOXIC GAS SILICON TETRA FLUORIDE.